

Care instructions:

- Materials and workmanship defects warranted for 5 years Valves and working parts warranted for 5 years
- Surface warranty defects warranted for 1 year •
- O-rings, hoses & gaskets warranted for 1 year
- Clean the mixers and showers regularly as required, using soap, do not use any other cleaners. Regular cleaning will prevent the build up of lime scale and dirt
- After cleaning rinse thoroughly with clean water to remove any cleaner residue
- Residues of liquid soaps, shampoos and shower foams can also cause damage, so rinse with clean water after using, avoid contact with any abrasives